

# CAST XFP

Networkable  
Analogue Addressable  
Fire Alarm Control Panel


1 Loop 16 Zone Panel  
Part No. **XFP501E/CA**

1 Loop 32 Zone Panel  
Part No. **XFP501/CA**

2 Loop 32 Zone Panel  
Part No. **XFP502/CA**

## User Manual & Log Book

Approved Document No. DFU5020000Rev 3



## CONTENTS

<b>Important safety notes</b> .....	<b>3</b>
<b>Introduction</b> .....	<b>4</b>
Fire alarm systems – an overview .....	4
The CAST XFP fire alarm control panel .....	4
An overview of the panel's access levels .....	4
<b>User responsibilities</b> .....	<b>5</b>
<b>Panel layout, indicators and controls</b> .....	<b>6-7</b>
<b>General user operation</b> .....	<b>8-11</b>
<b>(Messages that may appear on the panel's display and what they mean)</b>	
Normal conditions .....	8
Fire conditions .....	9
1st-stage fire conditions .....	10
Fault conditions .....	11
<b>Access level 1 (general user) controls and menu options</b> .....	<b>12-13</b>
Displaying fire, fault, disablement and test events .....	12-13
Testing the panel's lamps .....	13
Displaying the panel's alarm counter .....	13
<b>Access level 2 (authorised user) controls and menu options</b> .....	<b>14-19</b>
Silencing the alarm sounders .....	14
Resounding the alarm sounders .....	14
Resetting the panel .....	14
Displaying fire, fault, disablement and test events .....	15
Testing the panel's lamps .....	15
Displaying and clearing the panel's alarm counter .....	15
Changing the panel's time and date .....	16
Event log functions .....	16
Disabling or enabling parts of the system .....	17-18
Changing the access level 2 entry code .....	19
<b>Access level 1 and 2 menus structure</b> .....	<b>19</b>
<b>System set-up data chart</b> .....	<b>20</b>
<b>Fire alarm log book</b> .....	<b>21-24</b>

## Symbols



Read these instructions thoroughly before operation



Important Notes



Hints



## IMPORTANT SAFETY NOTES

### **READ THIS SECTION BEFORE OPERATING THIS PRODUCT.**

The fire alarm control panel is safe to operate provided it has been installed in accordance with the manufacturer's instructions and used in accordance with this user manual.

Hazardous voltages are present inside the panel. **DO NOT** operate the fire alarm control panel with the enclosure open. There is no need to open the enclosure except to carry out commissioning, maintenance and remedial work. This work must only be carried out by competent service personnel who are fully conversant with the contents of the separate Installation and Programming Manual for this product and have the necessary skills for maintaining the equipment.

If the panel is damaged in any way, expert advice should be sought regarding its repair.

Regular servicing of the fire alarm system is highly recommended, preferably on a continuous maintenance contract and by a competent organisation. A full-itemised installation report should be obtained at least annually.

## Disclaimer

Errors and omissions excepted. No responsibility can be accepted by the manufacturer or distributors of this range of fire panels for any misinterpretation of an instruction or guidance note or for the compliance of the system as a whole. The manufacturer's policy is one of continuous improvement and we reserve the right to make changes to product specifications at our discretion and without prior notice.

## INTRODUCTION

### Fire alarm systems - an overview

The primary purpose of a fire alarm system is to provide an early warning of a fire so that people and animals can be evacuated and action taken to stop the fire as soon as possible – all according to a predetermined plan.

Alarms may be raised by automatic detection devices, or manually by a person operating a manual call point (MCP).

To ensure an alarm is dealt with in an orderly manner, it is important to know where the alarm is coming from. To aid this function, fire alarm systems are usually split into zones, each covering a different geographical area of a building.

When an alarm has been raised, the panel responds by indicating the zone(s) in which the alarm has occurred and activating all relevant outputs (sounders, bells, strobes, beacons, relays, etc.) to provide a warning of the fire.

### The CAST XFP fire alarm control panel

The CAST XFP is an intelligent 'addressable' fire alarm panel designed to work with a wide range of 'CAST' compatible fire detection devices. As such, it is able to provide much more detailed information about a fire condition than just the number of the activated zone.

As well as giving prioritised feedback on the status of the system, the easy-to-read 80-character display will indicate the name and location of every detector that has responded to a fire and also show the order in which they went into alarm.

It will also display detailed information on any fault conditions that arise and can be programmed by an engineer to operate in a number of different ways to help reduce the incidence of false alarms and to encourage the orderly evacuation of a building in a true fire condition.

Controls are available that will allow authorised users to silence or reset a fire condition, to resound the alarm sounders, to disable or enable parts of the system to suit prevailing conditions, to change the panel's date and time and to test the panel's indicators to ensure they are working correctly.

All of these functions – and more – are explained in detail in this user manual.

### An overview of the panel's access levels

Three access levels are available at the panel – access level 1, access level 2 and access level 3.

Access level 1 is the general user level which is accessible to everyone. At this level you can:

- Scroll through any fire or fault conditions that are displayed on the panel's display
- View any disablements, or zones that are being tested
- Test the panel's lamps (LED indicators and display) to ensure they are working correctly
- Determine the total number of times the panel has been in a fire condition
- Gain entry to access level 2 (authorised user level) and, if you are an engineer, access level 3.

Access level 2 is the authorised user level which is accessible to authorised, trained personnel only. Access to this level is achieved by either, the input of a special four-digit code using the panel's pushbuttons, or by turning the panel's keyswitch to the armed position 'I'.

At access level 2, the panel's Silence, Reset and Investigate buttons become active and users are able to:

- Scroll through any fire or fault conditions that are displayed on the panel's display
- View any disablements, or zones that are being tested
- Enable or disable zones, sounders, outputs, relays and devices
- Display and/or reset the panel's event history
- Set the time and date
- Change the entry code to access level 2 from its factory default.

Access level 3 is the panel's engineering/programming level. On no account should access level 3 be accessed by anyone but an authorised system engineer. A fire panel is a piece of life safety equipment and unauthorised access may affect the way the panel functions, endanger life and void the warranty. If you are an engineer, details of access level 3 can be found in the separate engineering manual.

## USER RESPONSIBILITIES

BS5839-1 is the British Standard code of practice for the design, installation, commissioning and maintenance of fire detection and fire alarm systems for buildings. Section 7 of the standard (User Responsibilities) states that a named responsible person should be appointed to supervise all matters pertaining to the fire alarm system {clause 47.2a}.

Highlighted below is a summary of the main functions the responsible person is expected to carry out with regard to BS5839-1 only. It does not highlight any other responsibilities that may be required of the user or responsible person that are listed in documentation such as the Employers Guide to Fire Safety, the Fire Precautions (Workplace) regulations and/or any other legislation relevant to the premises. If in doubt, the fire authority can advise on the fire legislation that applies to any given building. For countries outside the UK, different user responsibilities may apply.

### BS5839-1 states the responsible person should:

(The bracketed numbers {xx} identify the BS5839-1 clauses to which the summary refers.)

- 1 Ensure the fire alarm panel is checked daily to confirm there are no faults on the system {47.2b}.
- 2 Ensure arrangements are in place for the test, maintenance and regular servicing of the system with regard to Section 6 of the standard {47.2c}. Important: Clause 44 of BS5839-1 recommends weekly and monthly tests that should be carried out by the responsible person. See below for details.
- 3 Ensure the Fire Alarm Log Book is kept up to date by recording fire signals, fault signals, work on the system, etc., and make sure it is available for inspection at all times {47.2d /48}.
- 4 Ensure all relevant occupants of the premises are instructed in the proper use of the system {47.2e}.
- 5 Take steps to limit the number of false alarms on the system {47f}.
- 6 Ensure the effectiveness of the system is not impaired by ensuring there is a space of at least 500mm in all directions around and below every fire detector and that all manual call points are unobstructed and easy to see {47g}.
- 7 Liaise with all relevant building engineers, decorators, etc., to ensure any changes to (or maintenance of), the building's fabric does not compromise the protection given by the fire alarm system, create faults or false alarms {47h}.
- 8 Ensure that any structural or occupancy changes planned for the building are done so with due and early consideration given to any changes that may be required to the fire system {47h}.
- 9 Ensure that a selection of spare parts are held as appropriate within the premises {47j}.

### Routine weekly testing to be undertaken by the user/responsible person

To meet the requirements of Clause 44 of BS5839-1 we recommend the following tests are carried out at approximately the same time each week, during normal working hours:

**Note:** It is essential any alarm receiving centre is contacted before, and after, these tests to avoid unwanted alarms and to confirm the fire signal is correctly received.

- Carry out an Indicator lamp test to check all zone lights show and the internal sounder activates.
- Operate a manual call point or automatic detector to test the fire alarm.
- Check that the alarm sounders operate.
- Reset the system by first pressing the Silence/Resound Sounders button and then pressing the Control Panel Reset button.
- Verify that no manual call points or automatic detectors are obstructed in any way.
- Test a different zone each week using a different call point or detector so all zones are tested in rotation.

### Routine monthly testing to be undertaken by the user/responsible person

Ensure authorised service personnel verify the system's standby power supply, or batteries, are in good working order.


### Quarterly and periodic inspection, testing, servicing and maintenance

It is the user's responsibility to ensure that an ongoing periodic plan is in place that meets Clause 45 (Inspection and Servicing) of BS5839-1. The work required to meet this Clause must be carried out by a competent person with specialist knowledge of fire detection and alarm systems. The standard recognises this will normally be an outside specialist fire alarm servicing organisation.


**Note:** The above summaries do not replace Sections 6 and 7 of BS5839-1 but are intended to help the user gain a greater understanding of his or her responsibilities. We strongly recommend the named responsible person familiarises themselves with the full standard, copies of which are available from the British Standards Institute, Customer Services Dept., 389 Chiswick High Road, London, W4 4AL. Tel: +44 (0)20 8996 9001. Web: www.bsi-global.com.

## PANEL LAYOUT, INDICATORS AND CONTROLS

### Front panel layout of single loop, 16 zone fire panel



### Front panel layout of one or two loop, 32 zone fire panel



## LED indicators

Liquid crystal display	Provides detailed info on the status of the fire alarm system, see pages 8 –11
(General) Fire	Flashes red when there is a fire condition on any zone and goes steady red when the alarm is silenced. Subsequent fire conditions will restart this indicator flashing until it is silenced again
Fire Zones	One or more of these indicators will flash red in an alarm condition to show which (1–16 or 1–32) zone(s) the fire is in and will go steady when silenced
Supply Present	Normally lit green to show that all of the panel's power supplies are functioning correctly
Test	Lit yellow when the panel is in walk test mode. This indicator does NOT light for any other test condition
Accessed	Lit yellow when the panel is in access level 2 or 3
General Disablement	Lit yellow when one or more zone, sounder, output or relay is disabled
Phased Evacuation	Flashes yellow when there is a phased evacuation in process
General Fault	Flashes yellow when there is a fault condition on the panel. Will always be lit in conjunction with at least one other fault indicator
Power Supply Fault	Lit yellow when the panel's power supply or Mains has failed or the panel's standby battery is in poor condition
System Fault	Lit yellow when a system error, such as a microprocessor fault, occurs AND REMAINS LIT EVEN IF THE SYSTEM FAULT CLEARS. THIS SYSTEM FAULT LED CAN ONLY BE CLEARED BY PRESSING THE CONTROL PANEL RESET BUTTON AT AL2/3.
Sounder Status	Flashes yellow if there is a faulty sounder or a sounder disablement anywhere on the system
Delays Running	Lit yellow when one or more output delays have been programmed by an engineer. Flashes yellow when one or more output delays are running.

## Button controls

More Information	Displays additional information on any fire or fault conditions that appear on the panel's display
(Scroll Up) ▲ (1) (Scroll Down) ▼ (3)	Dependent on the status of the panel, these two buttons: <ul style="list-style-type: none"> <li>• scroll vertically through any fire or fault conditions that appear on the panel's display</li> <li>• scroll vertically through the panel's user menus</li> <li>• manipulate date, time and disablement settings, etc.</li> <li>• select Yes/No in the panel's menu options</li> <li>• serve as code input buttons to access levels 2 or 3</li> </ul>
Accept ▶ (2) Escape ◀ (4)	Dependent on the status of the panel, these two buttons: <ul style="list-style-type: none"> <li>• scroll horizontally through the panel's user menus</li> <li>• escape or accept options available in the panel's user menus</li> <li>• serve as code input buttons to access levels 2 or 3</li> </ul>
Menu	Provides access to the panel's user menus
Silence Internal Sounder	Silences the panel's internal sounder
Control Panel Reset	Resets the panel when the sounders are silenced (access levels 2 & 3 only)
Silence /Resound Sounders	Silences or resounds the system's sounders (access levels 2 & 3 only)
Investigate	Starts the panel's investigate timer function (access levels 2 & 3 only). Only available if the panel's investigate function has been enabled by an engineer

## Keyswitch control



Turning the keyswitch to the armed position 'I' gives the user instant access to access level 2 (authorised user level). The key is non-removable in position 'I'.


## GENERAL USER OPERATION

### (MESSAGES THAT MAY APPEAR ON THE PANEL'S DISPLAY AND WHAT THEY MEAN)

At access level 1, the panel's display provides feedback on the system's current status. Priority is always given to the most important current event, i.e. fire conditions will override any fault conditions. This section (pages 8 – 11) outlines the various messages that may be displayed, what they mean and what action is required.

#### Normal conditions

In normal mode (when no fires or faults are occurring), one of the following messages will be displayed at the panel:



#### System status options

**Normal** is displayed when there are no fires or faults on the system and the panel's day/night (building occupied/unoccupied) facility HAS NOT been set up by the engineer.

**Normal: occupied** is displayed when there are no fires or faults on the system and the panel is in day (building occupied) mode.

**Normal: unoccupied** is displayed when there are no fires or faults on the system and the panel is in night (building unoccupied) mode.



Day/night (building occupied/unoccupied) settings are normally programmed by an engineer. They allow the system to operate differently dependent on the time of day with, for example, different detector sensitivity settings and lower sounder volumes.

**Outputs delayed** is displayed if one or more delays to outputs have been programmed by an engineer. It indicates that certain outputs (which may include sounders, relays and/or output units) will not trigger in the event of a fire alarm condition for a set period of time. Pressing the More Information button in a fire alarm condition will give more information about delays.

**Disablements active** is displayed if one or more disablements have been programmed by an authorised user or engineer. If required, you can view these disablements at access level 1. If you are an authorised user, you can cancel them (or set additional disablements) at access level 2.


**Zone tests active** is displayed if one or more of the fire alarm system's zones have been programmed into test mode by an engineer. When a zone is in test mode, any fire alarm conditions raised on it WILL NOT be reported to the panel in the normal way. As such, this message should only appear when an engineer is working on the system. If required, you can view which zones are in test mode at access levels 1 or 2. Zones can only be taken out of test mode by an engineer.




## Fire conditions

### In the event of a fire condition in a single zone:

- the panel's general Fire indicator will flash
- the panel's internal sounder will pulse
- the relevant Fire Zone indicator on the panel will flash
- the panel's display will show the number and name of the zone in fire (see example below)
- the system's sounders, relays and other output devices will operate as programmed by an engineer.




Pressing the More Information button will display the actual device that has triggered the fire condition, for example:



If more than one device is in a fire condition on the zone, the top left corner of the display will show, for example "1 of 3" and can be scrolled through using the ▲ and ▼ buttons.

### In the event of a fire condition on multiple zones:

- the panel's general Fire indicator will flash, the internal sounder will pulse and the relevant Fire Zone indicators will flash
- the panel's display will show the first and last zones that went into fire together with the total number of zones that are in fire. For example, if a fire condition has occurred in zones 1, 2 and 3 in that order, the display will show a message similar to the one below
- the system's sounders, relays and other output devices will operate as programmed by an engineer.



To view any additional zones that are in fire, press the ▲ or ▼ buttons as appropriate. The display will continue to show the last zone that went into fire but all previous zones will now appear on a step-by-step basis with details of which order they went into fire, i.e. 1st zone, 2nd zone, etc. Pressing the More Information button at any time will give you details of the actual device(s) that are in a fire condition on the zone that is on the top line of the display. These can be scrolled through using the ▲ and ▼ buttons.



**In the event of a fire condition, the building's fire management plan should always be executed.**

Authorised users can silence or reset the system by entering access level 2 and pressing the appropriate buttons on the panel's front. Details on how to do this can be found on page 14.

### Fire conditions with output delays

If a fire condition occurs on a zone that has been programmed (by an engineer) with one or more output delays, the panel will report the fire condition as described above but the panel's Delays Running indicator will flash yellow to indicate that one or more of the zone's assigned outputs has not yet triggered. Details of which outputs have delays running can be viewed by pressing the More Information button.

## 1st-stage fire conditions


On sites where there is a high incidence of nuisance alarms or where the consequence of a false alarm could result in the activation of, say, a sprinkler system, the fire officer may have permitted certain zones to be set up with:

- a **1st-stage zone dependency function** –to prevent the zone going into full alarm until certain other events have occurred on the same zone, such as a second device going into alarm, OR
- a **1st-stage investigation delay period** –to give the user time to investigate the cause of an alarm before a full alarm is initiated.

Details of any zones set up with 1st-stage alarm conditions should appear on the System Set-Up Data Chart on page 20.

### In the event of a 1st-stage fire condition (zone dependency or investigation delay):

- the panel's internal sounder will pulse
- the relevant Fire Zone indicator on the panel will flash
- the panel's display will show the number and name of the last zone which entered a "1st-Stage" fire condition (see example below).



### If the 1st-stage alarm is in a zone set up with a zone dependency function:

Press the More Information button to display the actual device that has triggered the 1st-stage fire condition (the display will also confirm that the panel is waiting for a confirmatory signal before going into full alarm). Pressing the More Information again will show how long is left before the panel auto-resets (returns to normal mode) should a confirmatory signal not be received.

### If the 1st-stage alarm is in a zone set up with an investigation delay period:

Press the More Information button to display the actual device that has triggered the 1st-stage fire condition (pressing More Information again will count down how long you have to invoke the zone's investigation delay period before it goes into full alarm).

#### To start the zone's investigation delay period:

Enter access level 2 (see page 14) and press the Investigate button. The period the investigation delay runs for will be as programmed by an engineer. Pressing More Information after the Investigate button has been pressed will display how long is left before the investigation period expires and the zone goes into full alarm.

If upon investigation you discover the fire condition is correct, you can override the delay by activating any manual call point in that zone.

Should any additional detection device(s) be activated in the zone being investigated during the recognition or delay periods, the panel will automatically put the zone into full alarm.

Should you discover the fire condition is false, you can silence or reset the 1st-stage fire condition at access level 2 (see page 14) and take appropriate action to clear the nuisance alarm.




In effect, the 1st-stage delay on a zone set up for investigation comprises two delays- the initial recognition period (where the user is expected to acknowledge the delay) followed by the investigation period itself.

## Fault conditions

If a part of the fire alarm system fails due to detector failure, wiring fault, etc.:


- one or more of the panel's Fault indicators will flash
- the panel's internal sounder will pulse
- the panel's display will show an appropriate fault message (in the case of a faulty manual call point, for example, the zone on which the faulty call point is located will be displayed):



Should there be more than one fault condition, the top right side of the display will read 'More. ↑↓' and you can scroll through them using the panel's ▲ or ▼ buttons.

Press the More Information button to view additional details about the displayed fault. For device specific faults, the actual device that has triggered the fault condition will be shown. For other faults, information pertinent to that fault will be displayed instead (if available).

For device specific faults, pressing the More Information button again will display the unique ID code and address location of the faulty device for the benefit of service engineers, etc.



**In the event of a fault condition, the designated responsible person on site should:**



- Mute the panel's internal sounder by pressing the Silence Internal Sounder button.  
**Note:** Any new faults will restart the internal sounder.
- Note down the nature of the fault(s) in the Fire Alarm Log Book (page 22)
- Take appropriate steps to ensure the fault(s) is/are rectified.


## ACCESS LEVEL 1 (General User) CONTROLS AND MENU OPTIONS

Accesslevel 1 is the general user level which is accessible to everyone. At this level you can:

- Scroll through any fire or fault conditions (as described on pages 9 –11)
- View any disablements, or zones that are being tested
- Test the panel's lamps (LED indicators and display) to ensure they are working correctly
- Determine the total number of times the panel has been in a fire condition
- Gain entry to accesslevel 2 (authorised user level) and, if you are an engineer, accesslevel 3.

Press the Menu button on the panel's front at accesslevel 1. The panel's general user menu is displayed (see Fig.1 below) which can be navigated using the panel's scroll (▲ ▼), Accept (▶) and Escape (◀) buttons as appropriate.

Each menu option available at accesslevel 1 is explained in detail below.



**Fig.1 : CAST XFP AccessLevel 1 Menu Structure**

\* Menu options shown will only appear if relevant to the panel's status. For example, DISPLAY FIRE EVENTS will not appear if there are no active fire conditions on the system.

### Enter accesslevel 2

Accesslevel 2 is for authorised users only and access to it requires the input of a special four digit code using the panel's pushbuttons, or by turning the panel's keyswitch to the armed position 'I'.

When the ENTER ACCESS LEVEL 2? prompt appears, press the Accept ▶ button and you will be asked to enter the code:

Enter AccessLevel 2 code:

Enter the accesslevel 2 code using the ▲ (1), ▶ (2), ▼ (3), ◀ (4) buttons as appropriate. The default code to accesslevel 2 is **3 3 3 3** (four presses of the ▼ button). If this does not work, the code may have been changed by an authorised user/engineer. A record of any changes should appear on the System Set-Up Data Chart on page 20 of this user manual. If they do not, contact your maintenance company.

As soon as the code has been entered correctly you will be taken into accesslevel 2. Additional panel controls and menu options will now be available (see pages 15 –19).

### Enter accesslevel 3

Accesslevel 3 is the panel's engineering level. ON NO ACCOUNT SHOULD ACCESS LEVEL 3 BE ACCESSED BY ANYONE BUT AN AUTHORISED SYSTEM ENGINEER. A FIRE PANEL IS A PIECE OF LIFE SAFETY EQUIPMENT AND UNAUTHORISED ACCESS MAY AFFECT THE WAY THE PANEL FUNCTIONS, ENDANGER LIFE AND VOID ITS WARRANTY. If you are an engineer, details of accesslevel 3 can be found in the panel's separate engineering manual.

### Display fire events

This function is only available if there are active fire conditions on the system. If available, select the menu option and press the Accept ▶ button once. A window similar to the one below will appear:

Last Zone: 1:North Stairs :Fire!  
1 Zone

Pressing the ▲ and ▼ buttons will scroll the display through all active fire conditions. More detailed information (if applicable) can be viewed by pressing the panel's More Information button. To return to the main access level 1 menu press the Escape ◀ button.

### Display fault events

This function is only available if there are active faults on the system. If available, select the menu option and press the Accept ▶ button once. A window similar to the one below will appear:

Zone 1: Ground Floor There are faults on this zone
---

Pressing the ▲ and ▼ buttons will scroll the display through all active faults. More detailed information (if applicable) can be viewed by pressing the panel's More Information button. To return to the main access level 1 menu press the Escape ◀ button.

### Display disablements

This function is only available when there are active disablements on the system. If available, select the menu option and press the Accept ▶ button once. A window similar to the one below will appear:

1st Zone: 1: Shop floor On: This Panel: Is Disabled
--

Pressing the ▲ and ▼ buttons will scroll the display through all active disablements. To return to the main access level 1 menu press the Escape ◀ button.

### Display zones in test

This function is only available if there are zones being tested. If available, select the menu option and press the Accept ▶ button once. A window similar to the one below will appear:

Zone 1: North Stairs Is On Test
------------------------------------

Pressing the ▲ and ▼ buttons will scroll the display through all zones in test mode. To return to the main access level 1 menu press the Escape ◀ button.

### Testing the panel's lamps

This function tests the panel's lamps (LED indicators and display) to ensure they are working correctly.

LAMP TEST? Display Alarm Counter	AL1
-------------------------------------	-----

Select the Lamp Test menu option and press the Accept ▶ button. All of the panel's LED indicators will illuminate steady for approximately two seconds and its display will progressively block fill. The panel's internal sounder will also sound. Upon completion, the panel will return to the main access level 1 menu. If any of the indicators fail to illuminate or the display does not function correctly, report the fault(s) to the designated site engineer and make a note of it in the Fire Alarm Log Book (page 22).

### Displaying the panel's alarm counter

This function displays the total number of times the panel has been in a fire alarm condition (a maximum of 999 counts). Select the Display Alarm Counter menu option and press the Accept ▶ button once. The display will show the total number of times the panel has been in a fire condition since it was installed AND the total number of times it has been in alarm since the alarm counter was last cleared, for example:

Total Alarms = 12 Alarms since 01/01/21=7
--

To return to the main access level 1 menu press the Escape ◀ button.

## ACCESS LEVEL 2 (Authorised User) CONTROLS & MENU OPTIONS

Access level 2 is available to authorised, trained personnel only. At this level, the panel's Silence/Resound Sounders, Control Panel Reset and Investigate buttons become active and you can:

- Scroll through any fire or fault conditions that are displayed on the panel's display
- View any disablements, or zones that are being tested
- Enable or disable zones, sounders, outputs, relays and devices
- Display and/or reset the panel's event history
- Set the time and date
- Change the entry code to access level 2 from its factory default.

Details of how to use the panel's Silence/Resound Sounders, Control Panel Reset and Investigate buttons can be found below.

### Entering accesslevel 2 - Using the pushbuttons on the panel

Entry to accesslevel 2 requires the input of a special four digit code.

Press the Menu button on the panel's front at accesslevel 1. When the ENTER ACCESS LEVEL 2? prompt appears, press the Accept ► button and you will be asked to enter the code:

Enter AccessLevel 2 code:

Enter the accesslevel 2 code using the ▲ (1), ► (2), ▼ (3), ◀ (4) buttons as appropriate. The default code to accesslevel 2 is **3 3 3 3** (four presses of the ▼ button). If this does not work, the code may have been changed by an authorised user/engineer. A record of any changes should appear on the System Set-Up Data Chart on page 20 of this user manual. If they do not, contact your maintenance company.

### Entering accesslevel 2 - Using the keyswitch on the panel

Entry to accesslevel 2 is gained by turning the panel's keyswitch to the armed position 'I'.

### Silencing the alarm sounders

To silence any active alarm sounders, enter access level 2 (see above) and press the Silence/Resound Sounders button. The alarm sounders will cease to sound and the panel's general Fire and relevant Fire Zone indicators will go steady.

Should a fire condition occur on another zone whilst the alarm sounders are silenced, the panel:

- Will activate the sounders programmed by an engineer for activation by the new zone(s) in alarm
- Will flash the general Fire and appropriate Zone indicator(s) for any new zone(s) in alarm
- May, if programmed by an engineer, automatically reactivate the silenced alarm sounders and flash any related Fire Zone indicator(s).

### Resounding the alarm sounders

Pressing the Silence/Resound Sounders button when the alarm sounders are silenced will resound them. Pressing the Silence/Resound Sounders button again will silence the alarm sounders.

### Resetting the panel

After the cause of an alarm has been cleared and the alarm sounders have been silenced (see above), the panel can be reset by pressing the Control Panel Reset button.


The panel will give a double beep to indicate the reset process has started and, after a few seconds, the Fire Zone indicators and general Fire indicator will go out to indicate the process is complete. If there are still any fire conditions on any zones, the panel will go back into alarm as before.



**Note:** The panel's Investigate button is only active if an engineer has programmed one, or more, zones to operate with a 1st-stage investigation delay period (see page 10 for detailed information on this feature).

When in access level 2 the panel's authorised user menu is displayed (see Fig.2 below) which can be navigated using the panel's scroll (▲ ▼), Accept (▶) and Escape (◀) buttons, as appropriate. Each menu option available at accesslevel 2 is explained in detail below.

**Fig.2 : CAST XFP AccessLevel 2 Menu Structure**



\* The menu options shown will only appear if relevant to the panel's status. For example, DISPLAY FIRE EVENTS will not appear if there are no active fire conditions on the system. If any of these menus appear, refer to their listings in accesslevel 1 (pages 12 - 13) for details of how they work.

**Enter accesslevel 3**

Accesslevel 3 is the panel's engineering level. ON NO ACCOUNT SHOULD ACCESS LEVEL 3 BE ACCESSED BY ANYONE BUT AN AUTHORISED SYSTEM ENGINEER. A FIRE PANEL IS A PIECE OF LIFE SAFETY EQUIPMENT AND UNAUTHORISED ACCESS MAY AFFECT THE WAY THE PANEL FUNCTIONS, ENDANGER LIFE AND VOID ITS WARRANTY. If you are an engineer, details of accesslevel 3 can be found in the panel's separate engineering manual.

**Testing the panel's lamps - AL2 (3333) > Lamp Test**

This function tests the panel's lamps (LED indicators and display) to ensure they are working correctly. When selected, press the Accept ▶ button and all of the panel's LED indicators will illuminate steady for approximately two seconds and the display will progressively block fill. The panel's internal sounder will also sound. Upon completion, the panel will return to the main accesslevel 2 menu. If any of the indicators fail to illuminate or the display does not function correctly, report the fault(s) to the designated site engineer and make a note of it in the Fire Alarm Log Book (page 22).

**Displaying & clearing the panel's alarm counter - AL2 (3333) > Display Alarm Counter**

This function displays the total number of times the panel has been in a fire alarm condition (a maximum of 999 counts). When selected, press the Accept ▶ button and the display will show the total number of times the panel has been in a fire condition since it was installed AND the total number of times it has been in alarm since its alarm counter was last cleared, for example:

Total Alarms = 12  
Alarms since 01/01/21=7

Press the Escape ◀ button to return to the main accesslevel 2 menu or, to clear the alarm counter, press the Accept ▶ button. A window similar to the one below will appear:

Clear to today's date?  
Alarms since 01/01/21=7

Press the Accept ▶ button once and the alarm counter will reset and start counting any new fire conditions from the current date today's date. A short confirmation message will confirm the change has been made before the display returns to the main accesslevel 2 menu.



### Changing the panel's time and date - AL2 (3333) > Set Time/Date

This function allows the panel's time and date to be adjusted. When selected, press the Accept ▶ button and the following window (or similar) will appear:

Set the time:-00:00

Use the ▲ and ▼ buttons to adjust the hour (the panel has a 24 hour clock).

When the correct hour is displayed, press the Accept ▶ button to move to the minutes field. Use the ▲ and ▼ buttons to adjust the minutes.

When the correct time is displayed, press the Accept ▶ button to alter the date.

A window similar to the one below will appear:

Set the time:-16:52  
 Set the date:-xx:xx:xx

Use the scroll ▲ ▼ and Accept ▶ buttons to set the day/month/year as appropriate. When correct, press the Accept ▶ button again and you will be returned to the main access level 2 menu.

### Event log functions - AL2 (3333) > Event Log Functions

This function allows you to view the panel's event log on the panel's display, or to reset it. When the EVENT LOG FUNCTIONS? prompt appears, press the Accept ▶ button and scroll down to the desired function using the ▼ button.

**Note:** The PRINT EVENT HISTORY function is for future.

#### AL2 (3333) > Event Log Functions > Display Event History

The DISPLAY EVENT HISTORY menu option, when selected, displays the panel's 499 event log on the display. For example:

Event 499 at 01/01/16 11:31:19  
 AccessLevel 2 entered

Initially only the last event will appear in the window but you can scroll through the list using the ▲ button to see previous saved events. When the log is full, the oldest record is replaced by the newest record. Events are listed in chronological order. When you have finished viewing the required events, press the Escape ◀ button to return to the previous menu.

#### AL2 (3333) > Event Log Functions > Reset Event History

The RESET EVENT HISTORY menu option, when selected, clears the log from the panel's memory. To help ensure it is not erased by mistake, a warning will appear when the Accept ▶ button is pressed:

Are you sure you want to erase  
 the Event log?

Press the Accept ▶ button to confirm you want to erase the log. The following window will appear whilst the log resets after which the panel will return you to the EVENT HISTORY MENU.

Resetting the Event History...  
 Resetting entry 499



## Disabling or enabling parts of the system - AL2 (3333) > Set/Clear Disablements

Selecting this menu option takes you to the disablements sub-menu which allows you to enable or disable zones, sounders, outputs, relays, individual devices, the panel's fault relay or output delays.

We strongly recommend all disablements are regularly reviewed and immediately enabled when no longer necessary as they can have a major effect on how the system works.

### AL2 (3333) > Set/Clear Disablements > Enable/Disable Zones

This function allows you to disable zones from reporting faults, fires, etc., and is normally used to temporarily disable a zone of detectors/callpoints in areas such as loading bays where they are prone to nuisance triggering from vehicle fumes. When selected, press the Accept ► button and a window similar to the one below will appear:

Zone: 1: Shop Floor Enabled
--------------------------------

Select the zone to be disabled/enabled using the ▲ and ▼ buttons. Press the Accept ► button and the zone's status (Enabled or Disabled) will flash. Next, use the ▲ and ▼ buttons to toggle between enabled and disabled and press the Accept ► button to select the desired option.

The window will now move to the next available zone allowing further enablements or disablements to be made. Alternatively, to return to the previous menu press the Escape ◀ button.

**Note:** If all the input devices on a zone have been individually disabled using the ENABLE/DISABLE DEVICES function described on page 18, the zone they belong to will also be disabled. If you try to re-enable a zone which has no enabled devices on it, a prompt appears saying this cannot be done. Instead you must first enable at least one device on the zone using the ENABLE/DISABLE DEVICES function before re-enabling the zone itself.

### AL2 (3333) > Set/Clear Disablements > Enable/Disable Sounders

This function allows you to disable one or more sounder groups from sounding in a fire condition. When selected, press the Accept ► button and a window similar to the one below will appear:

Sounder Group: 1
------------------

Select the sounder group (1 to 16 or ALL) to be disabled/enabled using the ▲ and ▼ buttons.

When the desired sounder group has been selected, press the Accept ► button once and the sounder group's status (Enabled or Disabled) will flash. Next, use the ▲ and ▼ buttons to toggle between enabled and disabled and press the Accept ► button to select the desired option. The window will now move to the next sounder group allowing further enablements or disablements to be made. Alternatively, to return to the previous menu press the Escape ◀ button.

### AL2 (3333) > Set/Clear Disablements > Enable/Disable Outputs

This function allows you to disable one or more output sets from sounding in a fire condition. It is typically used to disable, for example, auto-diallers and other ancillary equipment from activating during routine maintenance. When selected, press the Accept ► button and a window similar to the one below will appear:

Output Set: 1
---------------

Select the output set (1 to 16 or ALL) to be disabled/enabled using the ▲ and ▼ buttons.

When the desired output set has been selected, press the Accept ► button once and the output set's status (Enabled or Disabled) will flash. Next, use the ▲ and ▼ buttons to toggle between enabled and disabled and press the Accept ► button to select the desired option. The window will now move to the next output set allowing further enablements or disablements to be made. Alternatively, to return to the previous menu press the Escape ◀ button.

### AL2 (3333) > Set/Clear Disablements > Enable/Disable Relays

This function allows the disablement of one or more of the panel's 3 auxiliary relays from activating, as programmed. When selected, press the Accept ► button and a window similar to the one below appears:

Panel Relay:-1

Select the relay (1, 2 or 3) to be disabled/enabled using the ▲ and ▼ buttons.

When the desired relay has been selected, press the Accept ► button and the relay's status (Enabled or Disabled) will flash. Next, use the ▲ and ▼ buttons to toggle between enabled and disabled and press the Accept ► button to select the desired option. The window will now move to the next relay allowing further enablements or disablements to be made. Alternatively, to return to the previous menu press the Escape ◀ button.

### AL2 (3333) > Set/Clear Disablements > Enable/Disable Devices

This function allows loop devices to be disabled from reporting faults, fires, etc., and is normally used to temporarily disable detectors/callpoints that are nuisance tripping. When selected, press the Accept ► button and a window similar to the one below will appear:

Select Zones:-1: Shop Floor

Use the ▲ and ▼ buttons to select the zone where the device you wish to disable/enable is located. When selected, press the Accept ► button and a list of all devices that can be disabled or enabled in that zone will appear, e.g.

Shop Floor:-1: Gent WC  
Loop 1, Device 3: Enabled

Use the ▲ and ▼ buttons to scroll through the available devices. When the desired device appears, press the Accept ► button and the device's status (Enabled or Disabled) will flash. Next, use the ▲ and ▼ buttons to toggle between enabled and disabled and press the Accept ► button to select the desired option. The window will now move to the next device allowing further enablements or disablements to be made. Alternatively, to return to the previous menu press the Escape ◀ button.

**Note:** If all the input devices on a zone are individually disabled, the zone they belong to will also be disabled. If you try to re-enable a zone which has no enabled devices on it using the ENABLE/DISABLE ZONES function described on page 17, a prompt appears saying this cannot be done. Instead you must first enable at least one device on the zone before re-enabling the zone itself.

### AL2 (3333) > Set/Clear Disablements > Enable/Disable Fault Relay

This function can be used to suppress the panel's fault relay from activating in a fault condition. When selected, press the Accept ► button and the following window will appear:

Fault relay is:-Enabled

Use the ▲ and ▼ buttons to toggle between enabled and disabled and press the Accept ► button to select the desired option. Alternatively, to return to the previous menu press the Escape ◀ button.

### AL2 (3333) > Set/Clear Disablements > Enable/Disable Output Delays

This function can be used to globally disable, or enable, any delays to outputs that may have been programmed by an engineer. Note the enable/disable function is still selectable even if no delays have been programmed. When selected, press the Accept ► button and the following window will appear:

Delays to Outputs are:-  
Enabled

Use the ▲ and ▼ buttons to toggle between enabled and disabled and press the Accept ► button to select the desired option. Alternatively, to return to the previous menu press the Escape ◀ button.

## Changing the accesslevel 2 entry code

This function allows you to change the four digit code needed to enter the panel's accesslevel 2 menu options.

### AL2 (3333) > Change AccessLevel 2 Code

When selected, press the Accept ► button and the following window will appear:

Enter NEW AccessLevel 2 Code


Using the ▲ (1), ► (2), ▼ (3), ◀ (4) buttons, enter the new four digit accesslevel 2 entry code. After the fourth digit has been entered, the panel will request you confirm the new code by re-entering it.

Enter NEW AccessLevel 2 Code: \*\*\*\*  
 Confirm NEW AccessLevel 2 Code:

Enter the code again by pressing the ▲ (1), ► (2), ▼ (3), ◀ (4) buttons in same sequence. If the two codes match, the panel will accept the code and you will be taken back to accesslevel 2. If you type an incorrect confirmation code you will be prompted to start the new code entry sequence again.

BE SURE TO KEEP A RECORD OF THE NEW CODE ON PAGE 20 OF THIS USER MANUAL.

**Fig.3 : CAST XFP AccessLevel 1 and 2 Menu structure**



## SYSTEM SET-UP DATA CHART

**Important:** This page should be carefully completed by the system engineer prior to handover.

### Zone functions

Tick the appropriate column for each zone. **Note:** Zones 17–32 are only available on 1–32 zone panels.

Zone No.	Zone description	Set up for normal operation	Set up with dependencies	Set up with an investigate facility	Set up with output delays
1					
2					
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					
22					
23					
24					
25					
26					
27					
28					
29					
30					
31					
32					

### ACCESS LEVEL 2 (AUTHORISED USER) CODE

The factory default code for access level 2 (using the pushbuttons on the panel) is **3 3 3 3** (four presses of the ▼ key). If this code is changed, make a note of the changes here:

New access level 2 code     Date changed \_\_\_\_\_

### ADDITIONAL INFORMATION

We recommend any additional information the user needs to be aware of is detailed below:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Completed by \_\_\_\_\_ of \_\_\_\_\_ on \_\_\_ / \_\_\_ / \_\_\_

## FIRE ALARM LOG BOOK

It is recommended that this log book be maintained by a responsible person, who should ensure that every entry is properly recorded. In the UK, this is necessary to satisfy the recommendations of BS5839-1, compliance with which may be a requirement of legislation. If your premises are certificated under the Fire Precautions Act, failure to keep a suitable log book may be a breach of the requirements of the certificate, which is a criminal offence. In order to satisfy the requirements of BS5839-1 the following must be recorded:

- The name of the responsible person
- Brief details of the maintenance arrangements
- Dates and times of all tests, including fire drills
- Dates and times of all fires to which the system responds
- Dates and times of all false alarms
- Causes, circumstances surrounding and category of false alarms (if known)
- The identity of any manual call point or fire detector that triggers any of the above fire alarm signals (if known)
- Dates, times and type of all faults and defects
- Dates and times of all maintenance, e.g. service visit, or non-routine attention

USER:

SITE ADDRESS:

RESPONSIBLE PERSON(S) ON SITE:

THE SYSTEM WAS DESIGNED BY:

THE SYSTEM WAS INSTALLED BY:

THE SYSTEM WAS COMMISSIONED BY:

THE SYSTEM WAS ACCEPTED BY:

VERIFICATION WAS UNDERTAKEN BY:

### FOR SERVICE (DETAILS OF WHO YOU SHOULD CONTACT IF MAINTENANCE IS REQUIRED)

THE SYSTEM IS MAINTAINED UNDER CONTRACT BY:

Company: \_\_\_\_\_

Address: \_\_\_\_\_

Contact No: \_\_\_\_\_ Expiry Date: \_\_\_\_\_

NORMAL HOURS (MON-FRI) TEL: \_\_\_\_\_

OUTSIDE NORMAL HOURS TEL: \_\_\_\_\_

MANNED CENTRE TEL: \_\_\_\_\_

MANNED CENTRE CODE: \_\_\_\_\_

THE NORMAL MAXIMUM ATTENDANCE TIME FOR A MAINTENANCE TECHNICIAN IS: \_\_\_\_\_

EXPENDABLE COMPONENT REPLACEMENT PERIODS (LIST):

**CAST XFP 16 & 32 ZONE ANALOGUE ADDRESSABLE FIRE ALARM PANEL**

---

Details of tests (including fire drills), actual fire alarms, disablements, enablements and faults should be recorded here.

**Note:** BEFORE ENTERING DETAILS ON THIS FORM, PHOTOCOPY ADDITIONAL SHEETS FOR FUTURE USE.

DATE	TIME	EVENT e.g. test, fire alarm signal, fault	ZONE	DEVICE	ACTION REQUIRED	COMPLETED	INITIALS

**CAST XFP 16 & 32 ZONE ANALOGUE ADDRESSABLE FIRE ALARM PANEL**

---

DATE	TIME	EVENT e.g. test, fire alarm signal, fault	ZONE	DEVICE	ACTION REQUIRED	COMPLETED	INITIALS

**PHOTOCOPY ADDITIONAL SHEETS AS REQUIRED**

**CAST XFP 16 & 32 ZONE ANALOGUE ADDRESSABLE FIRE ALARM PANEL**

**False alarms**

DATE	TIME	ZONE	DEVICE THAT TRIGGERED THE ALARM SIGNAL	CAUSE (IF KNOWN)	BRIEF CIRCUMSTANCES (where cause is unknown, record activities in the area)	MAINTENANCE VISIT REQUIRED? (YES or NO)	FINDINGS OF MAINTENANCE TECHNICIAN	CATEGORY OF FALSE ALARM	FURTHER ACTION REQUIRED	DONE PLEASE TICK

**Maintenance work**

DATE	TIME	ZONE (WHERE APPLICABLE)	DEVICE (WHERE APPLICABLE)	REASONS FOR WORK	WORK CARRIED OUT	FURTHER WORK REQUIRED	SIGNATURE